


## BATTERY REPLACEMENT



1. **Power down panel:** Go to Advanced Settings and enter the Installer/Dealer/Master code, then select "Power Down"
2. **Remove Battery Door:** Remove the panel from the backplate or table stand and then use a small screwdriver to remove the plastic door covering the battery.
3. **Remove Battery:** Pull the fabric tab that is located under the battery to remove it from the panel.
4. **Install New Battery:** Install the new battery paying careful attention to polarity and being sure to place the fabric pull tab under the battery to make future removal easier.

Re-install Battery Door and screw, then re-mount to backplate or table stand.

**CAUTION:** Do NOT use a screwdriver or anything sharp that could puncture the battery.

## BATTERY REPLACEMENT

**WARNING:** Caution – The battery used in this device may present a risk of fire or chemical burn if mistreated. Do not disassemble, heat above 60°C, or incinerate. Replace battery with GUANGZHOU GREAT POWER ENERGY&TECHNOLOGY CO LTD, Ltd., Model ICR 18650 only. Use of another battery may present a risk of fire or explosion.

**WARNING:** Dispose of used battery promptly. Keep away from children. Do not disassemble and do not dispose of in fire. Dispose of used battery promptly. Keep away from children. Do not disassemble and do not dispose of in fire.